

WIRING USING STANDARD 5A CTs SHOWN. WHEN USING 5A CTs, ELKOR RECOMMENDS THE USE OF A SHORTING BLOCK.

mV AND mA (MCT/MSCT) STYLE CTs TYPICALLY DO NOT REQUIRE THE USE OF A SHORTING BLOCK AS THEIR OUTPUTS DO NOT PRODUCE DANGEROUS VOLTAGE LEVELS.

ALL CTs MUST BE MOUNTED ON RATED INSULATED CONDUCTORS.

ELHOR Technologies Inc.		
DRAWN: PCK	WattsOn-Mark II	CODE:
CHECKED: CKK	(1-element 2-wire)	
DATE: 2018/02/02	FILE: WattsOn-MkII - Wiring (1 phase).t4g	SHEET: 1 OF 1